



## Aqualite Weatherproof TV – RS-232 Information & Coding

Baud Rate = 38400 Data = 8 Parity = None Stop bit = 1

The RS-232 codes are in Hex form and as follows:-

<u>Functions</u>	<u>HAX Commands</u>
DTV--	A0 F0 55 FF 20 E0
TV--	A0 F0 55 FF 21 DF
VGA--	A0 F0 55 FF E9 17
YPBPR--	A0 F0 55 FF 22 DE
HDMI--	A0 F0 55 FF 23 DD
AV--	A0 F0 55 FF 24 DC
ON--	A0 F0 55 FF 27 D9
OFF--	A0 F0 55 FF 0A F6
VOL +	A0 F0 55 FF 58 A8
VOL –	A0 F0 55 FF 4B B5
CH+	A0 F0 55 FF 1F E1
CH-	A0 F0 55 FF 1E E2
MUTE	A0 F0 55 FF 0f f1

**Note;** some of the earlier Aqualite models do not have full RS232 functionality. AQLS-42 Serial numbers that start from 000316 have the following RS232 full Function codes & also have the ability to play all file formats via USB (apart from DivX)

<u>Functions</u>	<u>HAX Commands</u>
POWER_ON_OFF	A0 F0 55 FF 0B F4
DTV	A0 F0 55 FF E9 16



# AQUALITE OUTDOOR<sup>TM</sup>

---

<u>Functions</u>	<u>HAX Commands</u>
TV	A0 F0 55 FF E8 17
AV	A0 F0 55 FF ED 12
VGA	A0 F0 55 FF EA 15
HDMI	A0 F0 55 FF EC 13
COMPONENT	A0 F0 55 FF E7 18
PMODE	A0 F0 55 FF 4B B4
ZOOM	A0 F0 55 FF 51 AE
SURROUND	A0 F0 55 FF C7 38
SMODE	A0 F0 55 FF 5B A4
TEXT	A0 F0 55 FF 59 A6
VOL+	A0 F0 55 FF 0A F5
VOL-	A0 F0 55 FF 40 BF
CH+	A0 F0 55 FF 55 AA
CH-	A0 F0 55 FF 5A A5
MUTE	A0 F0 55 FF 14 EB
MENU	A0 F0 55 FF 4E B1
LEFT	A0 F0 55 FF 0C F3
SOURCE	A0 F0 55 FF 01 FE