


Quick Reference Guide


Aqualite TouchScreen with In-Built PC

The screen is default set to auto power on as you connect the screen to mains power. The source will be set to the PC Mode unless you change the source.

- (1) To power-up the PC, the power switch is located in the lockable compartment located underneath the screen. Simply toggle this switch in either direction to activate.



Also located here is a USB slot and HDMI socket, these can be used for example to connect a wireless mouse or any other HDMI device, media player etc. Please see the illustration below.



Please note: The featured USB and HDMI slots are added features which can be used for playing media/devices should you wish to use the panel as a standalone display device.

If you have any additional technical queries or questions, please contact:

Ashok Kumar – Aqualite Technician

+44 (0) 20 7586 6374

ashok@aqualiteoutdoor.com